Be Ember Aware

Protect your home from flying embers

Flying embers can travel miles in high winds during a wildfire. Below are tips to protect the most susceptible areas of your home from ignition by embers.

- Roof and gutters: Keep your gutters and rooftops free of debris. Clean regularly.
- Tree branches: Remove branches within 10 feet of your roof's edge and chimney openings.
- Dead, dying, or dry vegetation: Keep plants at least five feet away from your home. Use noncombustible groundcover, like gravel, in this area.
- Combustible items: Relocate anything that can burn at least five feet away from your home. This includes trash cans.
- **Grass and ground cover:** Keep grasses and ground cover under four-inches in height.

- Patio furniture: If wildfire is threatening, put combustible patio furniture inside or move it at least 30 feet away from the house.
- Venting and spark arrestors: Install spark arrestors on chimneys. Cover all vents with ¹/₈-inch, corrosion-resistant wire mesh or install vents designed to resist ember entry.
- Windows: Install dual-pane windows with one pane of tempered glass to reduce the chance of breakage in a fire.
- Fencing: Keep the base of fences free of debris. Choose fencing made with noncombustible material to prevent fire from extending to your home.

